

**\_none2**

code: \_none2

### **Program for humidity quantities conversion**

[Conversions](#) (650 kB) - program for conversions between humidity quantities, resistance temperature sensors and thermocouple conversions, liner transformations and current loop conversions. No installation needed, download exefile to disk and run.

### **Technical data**