

_none2

code: _none2

Program for humidity quantities conversion

<u>Conversions</u> (650 kB) - program for conversions between humidity quantities, resistance temperature sensors and thermocouple conversions, liner transformations and current loop conversions. No installation needed, download exefile to disk and run.

Technical data